PREMIER MOUNTS™
The original holding company

PaneLock™ Security System Installation Instructions

Security Hooks (Qty 2)		M6 x 12mm Security Screws (Qty 2)		Allen Wrench (Qty 1)	

This PaneLock™ Security System is to be used for all PCM-Series and CTM-Series mounts.

1. Slide the security hook up and behind the mounting crossbar.

2. Twist the security hook to the front and place over the mounting crossbar.

3. Insert the M6 x 12mm Security Screw and then tighten using the Allen Wrench (supplied).

4. Repeat these steps for the remaining security hook.